



# X/165LB

### POLYURETHANE BASED ADHESIVE FOR BONDING UPPERS TO SOLES

**X/165 LB** is an one-part, brush grade adhesive characterized by an excellent green strength, resistant to oily matter of leather and to PVC plasticizers as well as to water. The adhesive is suitable for bonding leather uppers and plastic uppers to vulcanized SBR, TR, polyurethane and PVC soles. It is particularly suitable in manufacturing processes where high temperature reactivation is required.

#### **CHARACTERISTICS**

**Composition** : polyurethane resin in a blend of organic solvents

Mode of setting : release of solvent

**Colour** : opalescent to transparent

Solvents : ketones

**Components** : one-part adhesive ready to use. It can be used with the addition of 2-3% of

**Desmodur RE** or **RFE** to improve the adhesion on to soles (e.g.

polyurethane soles and plastics uppers)

Pot life : 2 hours with the addition of the Accelerator

#### **TECHNICAL DATA**

**Solids content** : 17,5 - 18,5 %

Viscosity : 2000 - 2300 mPa.s (Brookfield spindle 4, spd 50, 25℃)

Values valid for product supply specification upon leaving the factory

## **METHOD OF USE**

# Preparation of the surfaces:

- Leather uppers and leather soles should be carefully roughed and brushed. Onto leathers having high grease content or onto materials where it is necessary to improve adhesive penetration, a first coat of **Primer 144/F** or **Primer C** in addition with 3% of Accelerator **Desmodur RE** or **RFE** should be applied.
- Polyurethane soles should solvent wiped with **ST/141**or roughed.
- PVC soles should solvent wiped with ST/141
- Vulcanized rubber soles: treat with **Primer AC/20** or **AC23/M**. In the presence of release substances it is recommended to solvent wipe with **ST/141** or to rough.
- TR rubber soles: treat with Primer AC/20 or AC23/M
- Plastic uppers: in case of PVC uppers solvent wipe with **ST/141.** In case of PU coated materials, check if any anti-adhesive finish was applied to the surface and remove it by solvent wipe using **ST/141**

**Application:** apply by brush a coat of adhesive on to both surfaces to be bonded. If a first coat of primer is required, this is to be applied some 5-10 minutes in advance.

**Drying of the adhesive:** allow to dry 15-20 minutes, then heat activate at a temperature of 70℃.

# **Technical Data Sheet**



X/165 LB

adhesives

**Assembly.** Bring the two parts into contact and apply pressure of 4-5 bars with 10-12 seconds dwell time. Bond strength gradually increases with time, reaching maximum value in 2 or 3 days after bonding.

Thinner: ST/121.

#### STORAGE STABILITY

12 months in the original sealed pack stored in a dry place at a temperature range +5℃+25°C.

All recommendations relating to the application and use of Fratelli Zucchini products have been given in good faith, based on the company's knowledge and experience. Products must be appropriately stored, handled and applied in normal conditions, as indicated on their respective Technical Datasheet. The variability of materials, substrates and conditions of use is such that no warranty of their functionality for a specific application can be deducted from this information, written recommendation or any other type of suggestion offered. Each user has the responsibility to make adequate evaluations on the efficacy of Fratelli Zucchini materials, products, services, recommendations and suggestions for the specific application required and must accomplish sufficient testing to ascertain that the final product will be safe and sound for the final purpose of the end-user. Fratelli Zucchini cannot be considered liable for any damage, direct or indirect derived from an incorrect use of the products